










- F Instructions de montage
- E Instrucciones de montaje
- I Istruzioni per il montaggio
- PT Instruções de montagem
- NL Montage-instructies
- PL Instrukcja montażu
- RU Инструкции по установке
- RO Instrucțiuni de montaj

PEUGEOT 5008, 5-portes/doors, 09-












3





x4




8




A




B




C






C



D






i






F Démontage  
E Desmontaje  
I Rimozione  
PT Remoção

NL Demontage  
PL Wymontowywanie  
RU СНЯТИЕ  
RO Demontare



8

x4



NORAUTO  
511/589 rue des Seringats  
59262 Sainghin-en-Mélantois  
FRANCE