


















- F Instructions de montage
- D Montageanleitung
- E Instrucciones de montaje
- I Istruzioni per il montaggio
- PT Instruções de montagem
- NL Montage-instructies
- PL Instrukcja montażu
- RU Инструкции по установке
- RO Instrucțiuni de montaj







RENAULT Clio, 5-portes/Türen/doors, 13-19





1




2





3







x4



x4



6





501-8010-03

x4


7




1



- F Serrer alternativement chaque côté
- D Ziehen Sie jede Seite abwechselnd an.
- E Apretar alternativamente
- I Alternare il serraggio delle viti
- PT Aperte alternadamente
- NL Afwisselend aan de linker- en de rechterkant aandraaien
- PL Śruby dokręcaj naprzemiennie
- RU Затягивайте попеременно
- RO Strângeți alternativ




A





B

x4



C




8




x4


A



B



C





x4





x4



x1



E
















F Démontage  
D Demontage  
E Desmontaje

I Rimozione  
PT Remoção  
NL Demontage

PL Wymontowywanie  
RU Снятие  
RO Demontare





NORAUTO:  
511/589 rue des Seringats  
59262 Sainghin-en-Mélantois  
FRANCE